


SHIELD/ARM ASSEMBLY INSTRUCTIONS

877-263-5737
www.buzzseating.com

IN THE BOX COMPONENTS



**5-legged Base & Casters
(Standard) OR
6-legged Base & Casters
(Heavy Duty)**



Cylinder




Telescoping Cover



Seat and Back



**Drop Away Arm
(Qty. 2)
OR
Adj. Loop Arm
Qty. 2)**



**Screws for Drop
Away (Qty. 6)**

**Screws for Adj.
Loop (Qty. 8)**

TOOLS REQUIRED!

Phillips Screwdriver OR Robertson #3

STEP 1

Slide plastic 3-piece telescoping cover
over pneumatic cylinder
BEFORE inserting into base.





STEP 2


Attach arms to seat using screws provided.



**6 Screws for
Drop Away Arm**





**8 Screws for
Adj. Loop Arm**



STEP 3

Insert cylinder into base, place assembled seat on top
of cylinder and apply downward pressure.



STEP 4

