



ASSEMBLY INSTRUCTIONS - SHIELD CHAIR




In The Box

Seat and Back



Base Cover



OR



Telescopic Cover
For 350-lb Capacity


Base Cover
For 500-lb Capacity

Pneumatic Cylinder




Base and Casters

OR




5-Prong Base
For 350-lb Capacity



6-Prong Base
For 500-lb Capacity


STEP 1

Cut and remove straps from outside of box.




STEP 2

Lift box up, exposing inner box and chair parts.




STEP 3

Slide cover over cylinder.




STEP 4

Insert cylinder into base.



STEP 6

Apply downward pressure to seat of chair.



STEP 5

Insert base with cylinder into chair body.

